



# Milesight Field Tester

**FT101**

User Guide




## Safety Precautions

Milesight will not shoulder responsibility for any loss or damage resulting from not following the instructions of this operating guide.

- ❖ The device must not be disassembled or remodeled in any way.
- ❖ Do not remove the battery of the device.
- ❖ Do not place the device and its accessories where the temperature or humidity is below/above the operating range.
- ❖ **Do not place the device close to objects with naked flames, otherwise it will explode.**
- ❖ The device must never be subjected to drops, shocks or impacts.
- ❖ Do not pull the antenna, detach them by holding the connectors.

## Copyright © 2011-2025 Milesight. All rights reserved.

All information in this guide is protected by copyright law. Whereby, no organization or individual shall copy or reproduce the whole or part of this user guide by any means without written authorization from Xiamen Milesight IoT Co., Ltd.



For assistance, please contact

Milesight technical support:

Email: [iot.support@milesight.com](mailto:iot.support@milesight.com)

Support Portal: [support.milesight-iot.com](http://support.milesight-iot.com)

Tel: 86-592-5085280

Fax: 86-592-5023065

Address: Building C09, Software Park III,  
Xiamen 361024, China

## Revision History

Date	Doc Version	Description
July 19, 2024	V 1.0	Initial version
Jan. 20, 2025	V 1.1	1. Add noise scan, pingpong and signal strength evaluation features 2. Update real-time testing feature 3. Add upgrade feature 4. Add real-time testing report packet

# Contents

1. Product Introduction .....	4
1.1 Overview .....	4
1.2 Features .....	4
2. Hardware Introduction .....	4
2.1 Packing List .....	4
2.2 Hardware Overview .....	5
2.3 Dimensions (mm) .....	5
3. SIM/SD Card Installation (Optional) .....	6
4. Operation Guide .....	7
4.1 Basic Gestures and Shortcuts .....	7
Button Shortcuts .....	7
Basic Gestures .....	7
4.2 Signal Test .....	8
4.2.1 LoRaWAN Setting .....	9
4.2.2 Noise Scan .....	11
4.2.3 PingPong Test .....	13
4.2.4 Signal Evaluation .....	15
4.2.5 Real-time Testing .....	20
4.3 Upgrade .....	25
Firmware Upgrade .....	25
App Upgrade .....	26
5. Maintenance .....	26
6. Communication Protocol .....	27
Appendix: Signal Quality Guidelines .....	28

## 1. Product Introduction

### 1.1 Overview

Milesight Field Tester is a portable LoRaWAN® network testing device. With different kinds of antennas, it can support global LoRaWAN® frequencies to record the signal status and packet loss rate to monitor the network status from the field and verify the coverage of different LoRaWAN® gateways, to optimize the best places to deploy LoRaWAN® devices.


Equipped with a 5.72-inch touchscreen display, users are able to operate the signal test procedure and monitor the real-time network status friendly. With a built-in battery and type-C port, it can work for 8 hours and supports type-C power bank charge to bring the device everywhere easily.


### 1.2 Features

- Octa-core processor with Android system and big memory for flexible integration
- Built-in one-channel SX1262 LoRaWAN® module for signal test
- Support global LoRaWAN® frequencies with different antennas
- Compatible with any standard LoRaWAN® gateways and global mainstream network servers
- Compatible Milesight ToolBox App to configure Milesight sensors via NFC or Bluetooth
- Support noise scan to optimize the locations and configurations of gateways
- Support signal evaluation to optimize the locations and configurations of devices
- Support to simulate the parameters of Milesight devices for accurate results
- Support to get RSSI and SNR of the gateway and statistics of packet loss rate between gateway and devices
- Support GNSS positioning to record the location of the test field
- Straightforward user interfaces presented on a 5.72-inch touchable LCD screen
- With a built-in rechargeable lithium battery that works for 8 hours
- Support real-time data backup and charge through a USB type-C port

## 2. Hardware Introduction

### 2.1 Packing List





**!** If any of the above items is missing or damaged, please contact your sales representative.

## 2.2 Hardware Overview




## 2.3 Dimensions (mm)



### 3. SIM/SD Card Installation (Optional)





1. Remove the rubber plug of the slot, and use an ejector tool to push the contact point to pop up the card slot.
2. Insert the nano SIM card (4FF) or micro SD card, then turn the slot over and restore it back to the device.
3. Restore the rubber plug of the slot.






## 4. Operation Guide





### 4.1 Basic Gestures and Shortcuts

#### Button Shortcuts

Item	Description
	<p><b>Power On:</b> press and hold on the Power button for 3s until the screen lights.</p> <p><b>Power Off or Restart:</b> press and hold on the Power button for 3s until the phone displays the Power off and Restart menu.</p>
	<b>Turn up the volume:</b> press the Volume up button.
	<b>Turn down the volume:</b> press the Volume down button.
	<b>Take a screenshot:</b> press the Volume down and Power buttons simultaneously.

#### Basic Gestures

Item	Description
	<b>Back to home screen:</b> tap the Home button once.
	<b>Return to the previous screen:</b> tap Return button once.
	<b>Access home screen edit mode:</b> tap Menu button once.

	<b>Recent tasks:</b> press and hold on Home button for a while to view recent tasks.
	<b>Close an app:</b> When viewing recent tasks, swipe up on an app preview to close the app.
	<b>Open Settings menu:</b> Swipe up from the bottom of home screen.
	<b>Display notification and shortcut switches panel:</b> swipe down from the upper edge of the screen.

## 4.2 Signal Test

Milesight field tester is equipped with a dedicated Field Tester App for LoRaWAN® signal testing. Please launch the Field Tester App and select below features according to the testing conditions on the spot:

Feature	Description
<b>No LoRaWAN® gateway on the spot</b>	
Noise Scan	Scan the noise of every frequency channel and provide a diagram for users to analyze the environmental interference condition, and select best installation locations and channel configuration for LoRaWAN® gateways.
PingPong Test	Simulate the uplink and downlink communication between end devices and the LoRaWAN® gateway. This requires at least 2 field tester devices.




**Has LoRaWAN® gateway on the spot**

Signal Evaluation	Simulate the end device to evaluate the signal strength quality of every spreading factor (datarate) by sending packets to the LoRaWAN® gateway. This is suitable for the situation which users do not know which spreading factor is the best option for end devices.
Real-time Testing	Simulate the end device to evaluate the signal strength quality by sending packets to the LoRaWAN® gateway. This is suitable for the situation which users already know which spreading factor or ADR will be used for end devices.

### 4.2.1 LoRaWAN Setting

Before starting all tests, it is necessary to launch the Field Tester App to configure the LoRaWAN® settings.

**Note:** after changing any parameters, the device will rejoin the network.



Ensure that the frequency channels match the testing gateway and configure the related parameters as required.

[illegible]

Parameters	Description
Band	<p>Select the frequency plan to send packets. If the band is one of CN470/AU915/US915, enter the index of the channel to enable in the input box, making them separated by commas.</p> <p><b>Examples:</b></p> <p>1, 40: Enabling Channel 1 and Channel 40</p> <p>1-40: Enabling Channel 1 to Channel 40</p> <p>1-40, 60: Enabling Channel 1 to Channel 40 and Channel 60</p> <p>All: Enabling all channels</p> <p>Null: Indicate that all channels are disabled</p>
SF (Spreading Factor)	Select a fixed spreading factor or select ADR to allow network server to adjust the spreading factor. This is used on Real-time Testing feature.
Tx Power	Select the transmit power mode of the device. This is used on Signal Evaluation and Real-time Testing features.

	<b>Native transmit power:</b> select the Tx power directly. <b>Mock sensor:</b> select the Milesight LoRaWAN device model. The tester will simulate the capability of this model to send packets.
Packet Dispatch Interval	Set the interval to report the packets. This is also the timeout when not receiving replies from LoRaWAN® gateway. Range: 6-60s, default: 10s.
Application Key	Set the Appkey for OTAA mode as required, the default value is 88888888888888888888888888888888.

### 4.2.2 Noise Scan

The field tester supports to simulate the gateway to scan the noise of specific LoRaWAN frequencies and give a diagram for users to analyze the environmental interference condition and select best frequencies.

1. Ensure the frequency plan of LoRaWAN settings is selected.
2. Place the field tester to the target location of LoRaWAN gateway.
3. Select **Noise Scan** button to configure related parameters, then click **Start** to scan.

**Note:** it is suggested to scan at least 1 hour for accurate results.

<

Noise Scan

Location

Location1 >

Longitude

118.031117°E

Latitude

24.624808°N


Scan Freq

General Freq >

Start

Parameters	Description
Location	Customize a name to indicate the test location.
Longitude	Show the coordinates of devices. It only works when placed outdoors.
Latitude	<b>Note:</b> 1) Ensure the Location is turned on in the Settings page of this device. 2) Download and launch App <b>GPS Test</b> if still not getting the coordinates.
Scan Freq	Set the frequency to scan the noise. <b>General Freq:</b> use the channels enabled in <a href="#">LoRaWAN Settings</a> . If the band is one of CN470/AU915/US915, the device will scan all channels. <b>Custom Freq:</b> set the start and end frequency of a range, and the frequency interval.

4. Click **Stop** to stop the scanning. The tester will display the RSSI result as graph or table. RSSI indicates the sensitivity for every frequency channel. The **lower the RSSI value, the better the signal**.



5. Click **Export** to save the test results as a CSV log file to the tester. You can also click **Start** to

start a new scanning.

Frequency	Current Scan (dBm)	Weighted Average Scan (dBm)	Location	Longitude	Latitude
902.3	-65	-66	Location1	118.03069° E	24.624923° N
902.5	-67	-67	Location1	118.03069° E	24.624923° N
902.7	-68	-67	Location1	118.03069° E	24.624923° N
902.9	-67	-67	Location1	118.03069° E	24.624923° N
903.1	-68	-67	Location1	118.03069° E	24.624923° N
903.3	-66	-66	Location1	118.03069° E	24.624923° N
903.5	-67	-67	Location1	118.03069° E	24.624923° N
903.7	-67	-67	Location1	118.03069° E	24.624923° N
903.9	-68	-67	Location1	118.03069° E	24.624923° N
904.1	-67	-67	Location1	118.03069° E	24.624923° N
904.3	-67	-67	Location1	118.03069° E	24.624923° N
904.5	-67	-66	Location1	118.03069° E	24.624923° N

### 4.2.3 PingPong Test

Two field testers support PingPong test feature to simulate the communication between end devices and gateway if there is not gateway on the spot.

1. Ensure the frequency plan of [LoRaWAN Settings](#) of both testers are the same.
2. Place one tester to the target location of end device, and the other to the target location of LoRaWAN gateway.
3. Select **PingPong** button of both testers to configure related parameters, then click **Start** of both devices.

**PingPong**

Location
Device >

SF ⓘ
SF7-DR3 >

TX Power ⓘ
TXPower0-30 dBm >

Frequency ⓘ
902.3 >

Longitude
118.030883°E

Latitude
24.624923°N

Role ⓘ
Slave >

Kit ID ⓘ
123456 >

Start

**PingPong**

Location
Gateway >

SF ⓘ
SF7-DR3 >

TX Power ⓘ
TXPower0-30 dBm >

Frequency ⓘ
902.3 >

Longitude
118.03069°E

Latitude
24.624923°N

Role ⓘ
Master >

Kit ID ⓘ
123456 >

Start

Parameters	Description
Location	Customize a name to indicate the test locations.
SF	Select the spread factor to send packets. This parameter of both devices must be the same.
Tx Power	Select the transmit power of both devices. This parameter of both devices must be the same.
Frequency	Set the frequency to send packets. This parameter of both devices must be the same.
Longitude	Show the coordinates of devices. It only works when placed outdoors.
Latitude	<b>Note:</b> 1) Ensure the Location is turned on in the Settings page of this device. 2) Download and launch App <b>GPS Test</b> if still not getting the coordinates.
Role	Set one device as Slave and the other one as Master.
Kit ID	Only the devices with the same kit ID can communicate with each other.

4. Click **Stop** to stop the scanning. The tester will display the result including uplink/downlink sending/receiving amounts, average RSSI/SNR, and packet loss rate.

PingPong

**Pairing results**

Item	Uplink Packet	Downlink Packet
Packet	5	5
OK	5	4
RSSI	-49	-41
SNR	12	13
PER	0%	20%

Location Device >

SF ⓘ SF7-DR3 >

TX Power ⓘ TXPower0-30 dBm >

Frequency ⓘ 902.3 >

Start

Export

PingPong

**Pairing results**

Item	Uplink Packet	Downlink Packet
Packet	6	5
OK	5	5
RSSI	-48	-41
SNR	12	13
PER	17%	0%

Location Gateway >

SF ⓘ SF7-DR3 >

TX Power ⓘ TXPower0-30 dBm >

Frequency ⓘ 902.3 >

Start

Export

5. Click **Export** to save the test results as CSV log files to both testers. You can also click **Start** to start a new testing.

Time	Tx Power (dBm) / SF	Total Packets (Master)	Successful Packets	RSSI (dBm, Master)	SNR (dB, Master)	Packet Loss Rate	Longitude	Latitude (Mas
2024/12/30 17:54	TXPower0-30 dB / SF7-DR3	5	5	-49	12	0	118.03069°	24.624923° N

## 4.2.4 Signal Evaluation

The field tester supports to evaluate the signal strength quality of every spreading factor (datarate) by sending packets to gateway. This guide will take the Milesight UG65 gateway as an example to operate the signal strength evaluation. Users can also connect this device to any standard LoRaWAN® network server.



1. Launch the Field Tester App, and find the device EUI and application key information.

**Note:** the app EUI (join EUI) is fixed as 24E124C0002A0001.

Device EUI	24E124
Application EUI	24E124C0002A0001
Application key	88888888888888888888888888888888
LoRaWAN Version	V1.0.3
Work Mode	Class A
Join Type	OTAA

2. Configure the [LoRaWAN® settings](#) of this field tester, and ensure the frequency band matches the settings of gateway.
3. Navigate to the web GUI of Milesight gateway to enable embedded NS mode.

The screenshot shows the 'General Setting' tab in the Milesight gateway web GUI. The left sidebar contains a menu with 'Status', 'Packet Forwarder', 'Network Server', 'Protocol Integration', 'Network', 'System', and 'Maintenance'. The main content area has tabs for 'General', 'Radios', 'Advanced', 'Custom', and 'Traffic'. Under 'General Setting', there are fields for 'Gateway EUI' (24E124FFFE), 'Gateway ID' (24E124FFF), 'Frequency-Sync' (Disabled), and 'Data Retransmission' (checkbox). Below these is a 'Multi-Destination' table:

ID	Enable	Type	Server Address	Connect Status	Operation
0	Enabled	Embedded NS	localhost	Connected	 

The screenshot shows the 'General Setting' tab in the Milesight gateway web GUI. The left sidebar contains a menu with 'Status', 'Packet Forwarder', 'Network Server', 'Protocol Integration', 'Network', 'System', and 'Maintenance'. The main content area has tabs for 'General', 'Applications', 'Payload Codec', 'Profiles', and 'Device'. Under 'General Setting', there is a red box around the 'Enable' checkbox (checked) and the 'Platform Mode' checkbox (unchecked). Below these are fields for 'NetID' (010203), 'Join Delay' (5 sec), 'RX1 Delay' (1 sec), 'Lease Time' (8760-0-0 hh-mm-ss), and 'Log Level' (info).

4. Navigate to **Network Server > Device** page to add the field tester to the gateway. The device profile type should be set as **OTAA-Class A**.



Device Name	FT101
Description	test
Device EUI	24e124
Device-Profile	ClassA-OTAA
Application	cloud
Payload Codec	None
fPort	1
Frame-counter Validation	<input type="checkbox"/>
Application Key	88888888888888888888888888888888
Device Address	
Network Session Key	
Application Session Key	
Uplink Frame-counter	0
Downlink Frame-counter	0

Save & Apply

After adding, the field tester will show network status is connected.

5. Place the field tester to the target location of end devices.
6. Select **Signal Evaluation** button, customize a name to record the detection location and click **Start** to test.

**Note:** **Signal Evaluation** button only displays when the device joins the network.

Location Location1 >

TX Power 12 dBm

Longitude -

Latitude -

Start

Parameters	Description
Location	Customize a name to indicate the test locations.
Tx Power	Show the tx power used in this evaluation. This can be set in <a href="#">LoRaWAN Settings</a> .
Longitude	Show the coordinates of devices. It only works when placed outdoors. <b>Note:</b>
Latitude	1) Ensure the Location is turned on in the Settings page of this device. 2) Download and launch App <b>GPS Test</b> if still not getting the coordinates.

7. After 1 minute, the tester will display the results and suggest the most recommended spreading factor (datarate). After evaluation, click **Apply** to change the SF of LoRaWAN setting to the most recommended value if required.

SF9-DR1	✓	Recommend
Signal Strength	<div> <div></div> <div></div> <div></div> </div> Strong	
RSSI/SNR	-34 dBm/11 dB	
RSSIS	-34	
Packet Loss Rate	0%	
SF7-DR3	✓	
Signal Strength	<div> <div></div> <div></div> <div></div> </div> Abnormal	
RSSI/SNR	-48 dBm/8 dB	
RSSIS	-48	
Packet Loss Rate	100%	

↺


Export

Apply

8. Click **Export** to save the test results as a CSV log file to the tester.

[illegible]

Users can also click the button at the top right corner of testing result or go to **Settings > Historical Reports** to check and export the test results.



### 4.2.5 Real-time Testing

This guide will take the Milesight UG65 gateway as an example to operate the real-time signal testing. Users can also connect this device to any standard LoRaWAN® network server.

1. Launch the Field Tester App, and go to **Settings > Basic Information** menu to find the device EUI and application key information.

**Note:** the app EUI (join EUI) is fixed as 24E124C0002A0001.

Device EUI	24E124
Application EUI	24E124C0002A0001
Application key	88888888888888888888888888888888
LoRaWAN Version	V1.0.3
Work Mode	Class A
Join Type	OTAA

2. Configure the [LoRaWAN® settings](#) of this field tester.
3. Navigate to the web GUI of Milesight gateway to enable embedded NS mode.

Status	General	Radios	Advanced	Custom	Traffic	
Packet Forwarder	General Setting					
Network Server	Gateway EUI 24E124FFFE					
Protocol Integration	Gateway ID 24E124FFF					
Network	Frequency-Sync Disabled					
System	Data Retransmission					
Maintenance	Multi-Destination					
	ID	Enable	Type	Server Address	Connect Status	Operation
	0	Enabled	Embedded NS	localhost	Connected	

Status	General	Applications	Payload Codec	Profiles	Device
Packet Forwarder	General Setting				
Network Server	Enable <input checked="" type="checkbox"/>				
Protocol Integration	Platform Mode <input type="checkbox"/>				
Network	NetID 010203				
System	Join Delay 5 sec				
	RX1 Delay 1 sec				
	Lease Time 8760-0-0 hh-mm-ss				
	Log Level info				

4. Navigate to **Network Server > Device** page to add the field tester to the gateway. The device profile type should be set as **OTAA-Class A**.


Device Name	FT101
Description	test
Device EUI	24e124
Device-Profile	ClassA-OTAA
Application	cloud
Payload Codec	None
fPort	1
Frame-counter Validation	<input type="checkbox"/>
Application Key	88888888888888888888888888888888
Device Address	
Network Session Key	
Application Session Key	
Uplink Frame-counter	0
Downlink Frame-counter	0

Save & Apply

After adding, the field tester will show network status is connected.

5. Place the field tester to the target location of end devices.
6. Select **Real-time Testing** button, customize a name to record the detection location and click **Start** to start the test, then the device will send the confirmed packets to the network server and record the testing results.

**Note:** **Real-time Testing** button only displays when the device joins to the network.



7. Click **Stop** to stop the test. The tester will display the signal test results and details.

**Note:** only after 1 minute the test can be stopped.

<

Real-Time Testing

Location

Location4 >

SF

SF9-DR1

TX Power

12 dBm

Signal Strength

Strong

RSSI/SNR

-50 dBm/11 dB

Uplink Packet

7

Confirm the package

7

Packet Loss Rate

0%

Longitude

-

Latitude

-

Go on

Export

8. Click **Export** to save the test results as a CSV log file to the tester.

Tx Cnt	Time	RSSI (dBm)	RSSI (dBm)	SNR (dB)	Signal	Uplink Packet	Confirm Packet	Packet Loss (%)	Longitude	Latitude	Location	SF	TX Power
1	2024/12/31 13:31	-94	-94		9 Middle	1	1		0 118.03076°24.625017°		Location4	SF9-DR1	12 dBm
2	2024/12/31 13:31	-88	-88		10 Middle	2	2		0 118.03076°24.625017°		Location4	SF9-DR1	12 dBm
3	2024/12/31 13:31	-90	-90		9 Middle	3	3		0 118.03076°24.625017°		Location4	SF9-DR1	12 dBm
4	2024/12/31 13:32	-94	-94		8 Middle	4	4		0 118.03076°24.625017°		Location4	SF9-DR1	12 dBm
5	2024/12/31 13:32	-94	-94		9 Middle	5	5		0 118.03076°24.625017°		Location4	SF9-DR1	12 dBm
6	2024/12/31 13:32	-92	-92		9 Middle	6	6		0 118.03076°24.625017°		Location4	SF9-DR1	12 dBm
7	2024/12/31 13:32	-85	-85		10 Middle	7	7		0 118.03076°24.625017°		Location4	SF9-DR1	12 dBm
8	2024/12/31 13:32	-84	-84		11 Middle	8	8		0 118.03076°24.625017°		Location4	SF9-DR1	12 dBm

Users can also click the button at the top right corner of testing result or go to **Settings > Historical Reports** to check and export the test results.



<

Historical Reports

Real-Time Testing

Signal Evaluation

2025-02

Location3

Middle

02-10 09:59

118.030988°E 24.624862°N

SF	SF7-DR5
RSSI/SNR	-92.42 dBm/9.08 dB
RSSIS	-92.42 dBm
TX Power	16 dBm

Uplink Packet	12
Confirm the package	12
Packet Loss Rate	0%

Start date — End date

Export

## 4.3 Upgrade

Field Tester supports to upgrade the device firmware or Field Tester App as required.

### Firmware Upgrade

1. Download FT101 device firmware from Milesight official website.
2. Connect the FT101 to the computer via type-C port.
3. Import the device firmware to the file folder of FT101 device.
4. Launch Field Test App, and navigate to **Settings > Basic Information** page.
5. Click **Select file** to select the firmware file and click **Upgrade** to upgrade the device.


Firmware upgrade

Select file


Upgrade

## App Upgrade

1. Ensure the FT101 device is able to access the Internet.
2. Launch Field Test App, and navigate to **Settings > Basic Information** page.
3. Click **App Upgrade** to download the latest App apk file from the Internet. You can also import the file to the device by connecting device to computer via type-C port if there is no Internet.



4. Open the apk file on the device folder to install it.



## 5. Maintenance

- Keep the device and its accessories dry. If the device sprayed the water, clean the surface with a dry soft cloth. Do not use an external heating device (such as a microwave oven) to dry it.
- Power off the device and disconnect the power adapter when cleaning the device.
- Do not clean the device and its accessories with strong chemicals, strong detergents or

solvents. To clean the device, wipe it with a soft moistened cloth. Use another soft, dry cloth to wipe dry.

- When installing a SIM card or micro SD card, keep the device clean to prevent impurities from entering the device.
- The response speed of the screen will become slow at a low temperature, which is a normal phenomenon and does not affect the performance.
- It is not suggested to charge the device when the environment temperature is over 45°C or below -10°C.
- Charge the device every 3 months if it is not used for an extended period.

## 6. Communication Protocol

The data are based on the following format (HEX), the Data field should follow little-endian:

Channel1	Type1	Data1	Channel2	Type2	Data2	Channel 3	...
1 Byte	1 Byte	N Bytes	1 Byte	1 Byte	M Bytes	1 Byte	...

For decoder examples please find files on <https://github.com/Milesight-IoT/SensorDecoders>.

Item	Channel	Type	Description
Protocol Version	ff	01	01=>V1
Hardware Version		09	01 40 => V1.4
Firmware Version		0a	01 14 => V1.14
Power On		0b	Device is on
Device Type		0f	00: Class A, 01: Class B, 02: Class C
Device SN		16	16 digits
Coordinate	03	a1	Byte 1-4: Longitude, INT32/1000000 Byte 5-8: Latitude, INT32/1000000
Signal Strength	04	a2	Byte 1-2: RSSI, INT16/10, Unit: dBm Byte 3-4: SNR, INT16/10, Unit: dB
SF (Spreading Factor)	05	a3	UINT8, range: 7-12 <b>Note:</b> when SF is set to ADR, the device will report this value as FF.
Tx Power	06	a4	INT16/100, Unit: dBm

### Examples:

1. **Basic Information:** reports whenever it joins the network.

ff0bff ff0101 ff166746d48016300014 ff090110 ff0a0101		
Channel	Type	Value
ff	0b (Power On)	ff

ff	01(Protocol Version)	01=V1
ff	16 (Device SN)	6746d48016300014
ff	09 (Hardware Version)	0100=>V1.0
ff	0a (Firmware Version)	0101=>V1.1

2. **Signal test packet:** reports when starting signal testing.

ff
----

3. **Real-time Testing packet:** reports everytime Real-time Testing stops.

03a1a801090779bf7701 04a279fc5d00 05a309 06a4b004		
Channel	Type	Value
03	a1 (Coordinate)	Longitude: a8 01 09 07=>07 09 01 a8=118030760/10^6=118.030760 Latitude: 79 bf 77 01=>01 77 bf 79=24625017/10^6=24.625017
04	a2 (Signal Strength)	RSSI: 79fc=>fc79= -903/10=-90.3dBm SNR: 5d 00=> 00 5d=93/10=9.3dB
05	a3(Spreading Factor)	09=SF9
06	a4 (Tx Power)	b0 04=>04 b0=1200/100=12 dBm

## Appendix: Signal Quality Guidelines

Signal Quality	Packet Loss Rate	SF	RSSIS
Strong	$\leq 5\%$	SF7	$\geq 60\text{dBm}$
		SF8	
		SF9	
		SF10	
		SF11	
		SF12	
Medium	$5\% < \text{Rate} \leq 10\%$	SF7	$-100\text{dBm} \leq \text{RSSIS} < 60\text{dBm}$
		SF8	
		SF9	
		SF10	
		SF11	
		SF12	
Weak	$10\% < \text{Rate} < 50\%$	SF7	$-115\text{dBm} \leq \text{RSSIS} < -100\text{dBm}$
		SF8	$-120\text{dBm} \leq \text{RSSIS} < -100\text{dBm}$
		SF9	$-125\text{dBm} \leq \text{RSSIS} < -100\text{dBm}$
		SF10	$-130\text{dBm} \leq \text{RSSIS} < -100\text{dBm}$
		SF11	$-135\text{dBm} \leq \text{RSSIS} < -100\text{dBm}$
		SF12	$-141\text{dBm} \leq \text{RSSIS} < -100\text{dBm}$

Abnormal	$\geq 50\%$	SF7	< -110dBm
		SF8	< -120dBm
		SF9	< -125dBm
		SF10	< -130dBm
		SF11	< -135dBm
		SF12	< -141dBm

**-END-**